

# Mouldings and Cornices

When installing 16ft mouldings, apply pressure (pressure-fit) to adjust. Position the dentil or design pattern carefully, to avoid overlapping.

1- Press-fit (or clamp) installation.

2- 45 degree angle joint installation.

