



General Installation Guide

PLASTIKA architectural mouldings and ornaments are made of high density polyurethane and Cellular PVC. Just like wood, our products are easy to install, cut, drill (screw), glue, repair and paint.

- 1) **Cutting:** Polyurethane and Cellular PVC should be handled like wood; therefore you can cut your ornaments using any woodworking tool. CAUTION! Some CUSTOM MADE pieces may contain screws.
- 2) **Gluing:** Lightly sand and apply PL PREMIUM polyurethane adhesive to the back of your ornament to be mounted in place or to connect your joints. Cellular PVC adhesive should be used for gluing Cellular PVC products together.
- 3) **Screwing:** Always use galvanised or treated screws, when mounting your ornaments. You can also use our Cortex screws and plug.
- 4) **Finishing:** For filling screw holes or end joints, use a caulking, putty pencil or polyester based glazing putty.
- 5) **Painting:** All PLASTIKA polyurethane pieces are finished in a white 100% acrylic exterior paint and all purchases of PLASTIKA products include touch-up paint. You also have the option of painting your ornaments; lightly sand the surface then apply a good quality exterior paint.

For more information or to request a catalogue, please do not hesitate to contact us at: 450-456-3409 or toll free 1-888-846-4419.

Thank you for choosing Plastika products!

The warranty will be void if the installation instructions are not followed.