


Installation Guide - Columns 1296 & 1297



The warranty will be void if the installation instructions are not followed.