


Installation Guide - Columns 1500-C, 1502-C & 1202



The warranty will be void if the installation instructions are not followed.